



**EVER WONDERED WHAT OUR
PART NUMBERS
REALLY MEAN?**

HOW TO READ OUR PART NUMBERS

HVFD3B3C0150G131B

FAMILY

D - VFD
B - VFD BYPASS

HP

Is always a 4-digit
number - with an extra 0
(e.g., '0150' = 15 HP)

BYPASS TYPE

0 - No Bypass Option
1 - Manual Bypass
2 - Manual Bypass w/ Soft Start
3 - Auto Bypass
4 - Auto Bypass and Soft Start

VOLTAGE

A - 208/230v
C - 460v
D - 600v

NEMA RATING

1 - NEMA 1
2 - NEMA 12
3 - NEMA 3R
4 - NEMA 3R w/ Heater

CONTACTORS

0 - Drive Only
1 - Fused Disconnect Only
2 - 2 Contactor Bypass w/ Fused Disconnect
3 - 3 Contactor Bypass w/ Fused Disconnect
4 - Circuit Breaker Disconnect Only
5 - 2 Contactor Bypass w/ Circuit Breaker Disconnect
6 - 3 Contactor Bypass w/ Circuit Breaker Disconnect

